

Technical Guide Book

The Right Choice



TaeguTools

★ ★ Ferramentas Premium ★ ★

 Rotating


 Non-Rotating



TaeguTec
Member IMC Group

CONTENTS »»

04 Turning



Selection Guide	6-10
Troubleshooting	11-13

14 Parting & Grooving



Selection Guide	16-17
Technical Tips	18-21
Troubleshooting	22-25

26 Drilling



Selection Guide	28-29
Technical Tips	30-31
Troubleshooting	32-35

36 Milling



Selection Guide	38-41
Troubleshooting	42-45

46 Solid End Mills




Selection Guide	48-50
MAXI-RUSH Recommended Cases	51
Troubleshooting	52-53

The Right Choice



Technical Guide Book

The Right Choice



Turning

Selection Guide
Troubleshooting





Steel (HB 200-220)

FINISHING

FS
CNMG 090404 FS TT8115B
Vc : 300-250
fn : 0.07-0.30
ap : 0.25-1.5

FM
CNMG 090408 FM TT8115B
Vc : 300-230
fn : 0.10-0.35
ap : 0.3-2.0

FT
CNMG 090408 FT TT8115B
Vc : 280-220
fn : 0.10-0.40
ap : 0.5-3.0

ROUGHING

FLP
CNMG 120404 FLP TT8115B
Vc : 300-250
fn : 0.08-0.30
ap : 0.2-2.0

MLP
CNMG 120408 MLP TT8115B
Vc : 300-230
fn : 0.10-0.40
ap : 0.5-3.5

MGP
CNMG 120408 MGP TT8115B
Vc : 280-220
fn : 0.15-0.55
ap : 0.5-5.0

RGP
CNMG 120412 RGP TT8125B
Vc : 250-200
fn : 0.25-0.70
ap : 2.5-6.0

Ni Nickel based Super alloys

FINISHING

EA
CNMG 120408 EA TT3010 / TT3020
Vc : 90-30 85-30
fn : 0.07-0.40 0.07-0.40
ap : 0.15-1.5 0.15-1.5

MGS
CNMG 120408 MGS TT3020
Vc : 40-20
fn : 0.15-0.40
ap : 1.0-4.0

ET
CNMG 120412 ET TT9080
Vc : 40-20
fn : 0.17-0.45
ap : 1.2-5.5

ROUGHING

-GX -GN
RCGX & RNGN 1207 TC3020 / TC3030
Vc : 350-250 250-150
fn : 0.05-0.30 0.05-0.30
ap : 0.1-4.0 0.1-4.0

High temp. alloys (HB 300-350)

Ti Titanium alloys

MK
CNMG 090408 MK TT3010
Vc : 90-30
fn : 0.05-0.20
ap : 1.0-3.0

MGS
CNMG 120408 MGS TT3010
Vc : 80-50
fn : 0.15-0.40
ap : 1.0-4.0

MGS
CNMG 120412 MGS K10
Vc : 70-45
fn : 0.17-0.50
ap : 1.5-4.0

Stainless steel (HB 160-180)

FINISHING

EA
CNMG 090404 EA TT5080 / TT9215
Vc : 200-130
fn : 0.05-0.30
ap : 0.2-1.5

MK
CNMG 090408 MK TT9225
Vc : 170-130
fn : 0.20-0.50
ap : 1.0-3.0

EM
CNMG 090408 EM TT9225
Vc : 120-60
fn : 0.13-0.40
ap : 0.5-3.0

ROUGHING

EA
CNMG 120404 EA TT5080 / TT9215
Vc : 200-130
fn : 0.05-0.30
ap : 0.15-1.5

MP
CNMG 120408 MP TT9225
Vc : 170-130
fn : 0.12-0.40
ap : 1.0-4.0

EM
CNMG 120408 EM TT9080 / TT9225
Vc : 120-60
fn : 0.13-0.50
ap : 0.5-5.0

ET
CNMG 120412 ET TT8080 / TT9235
Vc : 120-60
fn : 0.20-0.60
ap : 1.2-5.5

Small Parts Turning

LOW DEPTH

For medical parts

FS-F
VNGX 130402M FS-F TT4430
Vc : 120-100
fn : 0.04-0.12
ap : 0.2-1.0

FU-F
DNGG 130502M FU-F TT4430
Vc : 120-100
fn : 0.04-0.12
ap : 0.2-2.5

ST-R-F
DNGX 130504M ST-R-F TT4430
Vc : 120-100
fn : 0.05-0.12
ap : 0.7-5.0

Miniature industry (G tolerance)

SL-F
DCGT 11T302M SL-F TT4410/TT4430
Vc : 120-100
fn : 0.02-0.10
ap : 0.02-0.25

SA
DCGT 11T302 SA TT9020
Vc : 120-100
fn : 0.02-0.15
ap : 0.1-2.5

SM-F
DCGT 11T302M SM-F TT4430
Vc : 120-100
fn : 0.02-0.12
ap : 0.2-1.5

ST-F
DCGT 11T304M ST-F TT4430
Vc : 120-100
fn : 0.05-0.12
ap : 0.7-5.0

1st Recommendation

Vc cutting speed : m/min

fn feed rate : mm/rev

ap depth of cut : mm

1st Recommendation

Vc cutting speed : m/min

fn feed rate : mm/rev

ap depth of cut : mm



				
 Cast iron (HB 220-250)	Carbide Grade	MA-  CNMA 120412 TT7025 Vc : 280-220 fn : 0.15-0.70 ap : 1.5-6.0	KT  CNMG 120408 KT TT7015 Vc : 300-250 fn : 0.19-0.53 ap : 0.38-7.0	MT  CNMG 120408 MT TT7005 Vc : 330-280 fn : 0.17-0.55 ap : 1.2-5.0
	CBN & Ceramic Grade	 CNGA 120412 AS10 CNGX-CH 120712 T7 AS500 Vc : 800-250 1000-300 fn : 0.05-0.25 0.05-0.30 ap : 0.1-3.0 0.1-3.5	 RNGN 120400 SD TB7020 Vc : 1200-200 fn : 0.05-0.30 ap : 0.1-3.0	 CNGX 120412 DA TB7020 Vc : 1200-300 fn : 0.05-0.40 ap : 0.1-4.0

 Hardened steel	Carbide & Ceramic Grade (HRC ≥ 40)	 LOW SPEED			 HIGH SPEED
		 CNMG 120408 TT2010 Vc : 200-50 fn : 0.15-0.55 ap : 0.5-3.0	 CNGA 120408 AB30 Vc : 170-120 fn : 0.10-0.20 ap : 0.5-1.5	 CNGA 120408 AB20 / AB2010 Vc : 200-150 fn : 0.10-0.18 ap : 0.4-1.2	
	CBN Grade (HRC ≥ 50)	 CNGA 120408 TB670 Vc : 200-100 fn : 0.10-0.20 ap : 0.1-0.7	 CNGA 120408 TB2015 Vc : 250-150 fn : 0.08-0.15 ap : 0.1-0.6	 CNGA 120412 TB650 Vc : 250-150 fn : 0.08-0.15 ap : 0.1-0.6	 CNGA 120412 TB610 Vc : 300-200 fn : 0.10-0.20 ap : 0.1-0.5


 : 1ST Recommendation

• Vc cutting speed : m/min • fn feed rate : mm/rev • ap depth of cut : mm

Trouble





Productivity






Burr

Solutions

- Use high-speed grades**
 TT81xxB CVD grades 

 - Use high feed and high productivity inserts**
  High feed insert
  
 Multidirectional and high feed back turning Bi-directional high feed turning Double-feed at the same surface finish
 XNMV ZNMV TNMV FCMX WS WA WT
 - Use high-pressure coolant (Max. 70bar)**
 -TB Holder (2x speed up) 

 - Use high stability holder**
 QH- / QS- Head and Shank 
 7xD, 10xD, 12xD, 14xD
- Change insert geometry**

Cutting edge  Sharp edge	Nose radius  Small R	Entering angle  Small angle
---	---	--
 - Use PVD grade or ground insert at low feed**
 TT5080, TT8020, TT9080, TT3010, TT3020... PVD grade
 - Pre-machine of chamfer or round at start / end of workpiece**
 Chamfer  Radius



Trouble




Tangled Chip




Solutions



1 Change cutting conditions



2 Change insert geometry




3 Use high-pressure coolant (Max. 70bar)

-TB Holder



Trouble





Bad Surface Finish



Solutions



1 Change cutting conditions



2 Use wiper or bigger nose radius insert




3 Use high-pressure coolant (Max. 70bar)

-TB Holder






Over Breaking Chip

1 Change cutting conditions




2 Change insert geometry






3 Use external coolant

Vibration

1 Change cutting conditions



2 Change insert geometry



3 Use strong holder and anti-vibration bar

T-holder



HUSH-BORE and Carbide shank




7xD, 10xD, 12xD, 14xD

The Right Choice

Technical Guide Book

The Right Choice



Parting & Grooving

Selection Guide
Technical Tips
Troubleshooting




		P Steel (HB 200-220)	K Cast iron (HB 220-250)	M Stainless steel (HB 180-200)	S High temp. alloys (HB 300-350)	N Non-ferrous	H Hardened steel
Parting	Deep Parting Deep Grooving	 SFC TT9080 (Vc 150-100, fn 0.1-0.4)	 TDC TT9080 (Vc 180-120, fn 0.1-0.4)	 SFC TT9080 (Vc 120-80, fn 0.1-0.15)	 SFJ TT9080 (Vc 60-30, fn 0.08-0.12)	 TDJ K10 (Vc 330-150, fn 0.1-0.5)	 TSG-H TB2015 (Vc 60-120, fn 0.02-0.16)
	Tube Parting	 SFC TT9080 (Vc 150-100, fn 0.1-0.4)	 TDC TT9080 (Vc 180-120, fn 0.1-0.4)	 SFJ TT9080 (Vc 120-80, fn 0.1-0.15)	 SFJ TT9080 (Vc 60-30, fn 0.08-0.12)	 TDJ K10 (Vc 330-150, fn 0.1-0.5)	 TSG-H TB2015 (Vc 60-120, fn 0.02-0.16)
	Shallow Parting Shallow Grooving Precision Grooving	 TQC TT9080 (Vc 150-100, fn 0.06-0.15)	 TQC TT9080 (Vc 180-120, fn 0.1-0.4)	 TQJ TT9080 (Vc 120-80, fn 0.05-0.13)	 TQJ TT9080 (Vc 60-30, fn 0.08-0.12)	 TQS TT4430 (Vc 330-150, fn 0.1-0.5)	 TSG-H TB2015 (Vc 60-120, fn 0.02-0.16)
Grooving		 TDC TT9080 (Vc 150-100, fn 0.1-0.4)	 TDC TT9080 (Vc 180-120, fn 0.1-0.4)	 TDJ TT9080 (Vc 120-80, fn 0.1-0.15)	 TDCT TT9080 (Vc 60-30, fn 0.08-0.12)	 TDJ K10 (Vc 330-150, fn 0.1-0.5)	 TSG-H TB2015 (Vc 60-120, fn 0.02-0.16)
Groove Turning		 TDXU TT9080 (Vc 150-100, fn 0.1-0.4)	 TDCT TT6080 (Vc 180-120, fn 0.1-0.4)	 TDCT TT9080 (Vc 120-80, fn 0.1-0.15)	 TDCT TT9080 (Vc 60-30, fn 0.1-0.15)	 TDCT K10 (Vc 330-150, fn 0.1-0.5)	 TSG-H TB2015 (Vc 60-120, fn 0.08-1.20)
Face Grooving		 TDCT TT9080 (Vc 150-100, fn 0.1-0.4)	 TDCT TT6080 (Vc 180-120, fn 0.1-0.3)	 TDCT TT9080 (Vc 120-80, fn 0.1-0.15)	 TDCT TT9080 (Vc 60-30, fn 0.1-0.15)	 TDCT K10 (Vc 330-150, fn 0.1-0.4)	 TSG-H TB2015 (Vc 50-100, fn 0.02-0.14)
Profiling		 TDT-RU TT9080 (Vc 150-100, fn 0.1-0.4)	 TDT-RU TT6080 (Vc 180-120, fn 0.1-0.4)	 TDT-RS TT9080 (Vc 120-80, fn 0.1-0.15)	 TDT-RS TT3010 (Vc 60-30, fn 0.1-0.15)	 TDA K10 (Vc 330-150, fn 0.1-0.4)	 TSG-H TB2015 (Vc 60-120, fn 0.03-0.30)
Internal Grooving		 TQIS TT9080 (Vc 150-100, fn 0.1-0.4)	 TQIS TT9080 (Vc 180-120, fn 0.1-0.3)	 TQIS TT9080 (Vc 120-80, fn 0.1-0.15)	 TDCT TT9080 (Vc 60-30, fn 0.1-0.15)	 TDCT K10 (Vc 330-150, fn 0.1-0.4)	 TSG-H TB2015 (Vc 60-120, fn 0.02-0.16)
		 TMIR/L TT4430 (Vc 50-100, fn 0.01-0.1)	 TDIM TT9080 (Vc 70-110, fn 0.02-0.1)	 TMIR/L TT4430 (Vc 40-70, fn 0.01-0.1)	 TMIR/L TT4430 (Vc 20-40, fn 0.01-0.1)	 TMIR/L TT4430 (Vc 100-300, fn 0.01-0.1)	

(Vc cutting speed: m/min, fn feed rate: mm/rev)




Holder and Blade Size Selection


: To minimize vibration and deflection



- Blade or tool holder with the smallest possible overhang (CDX)
- Tool holder with the maximum shank size
- Blade or tool holder with the maximum width of insert seat size





Holder
For short overhang





Blade
For long overhang

90° Mounting of Tool Holder

: To get perpendicular surface and minimize vibration




- Insert must be mounted **90°** to the workpiece
- Mounting the holder as close to the chuck as possible




Recommended Feed Rate for Parting-off


: To increase tool life and productivity



- Reduce feed up to **70-80%** before 2.0-2.5 mm from the center
- Recommended feed rate $f_2 = f_1 \times 0.2 \sim 0.3$ (mm/rev)





$$f_2 = f_1 \times 0.2$$



$$f_2 = f_1$$

Cutting Edge Height Set-up


: To prevent over wear and breakage of insert and short tool life




- Cutting edge height set-up within maximum **± 0.1 mm**
- Parting-off should be as close to the chuck as possible
- When machining long overhang, set the cutting edge height **+0.1 mm** higher to compensate for tool deflection

Handed Type Insert with Lead Angle

: To minimize pips or burrs



Handed insert



Neutral insert


- Use lead angle insert only to reduce burrs
- Recommended lead angle by application
 - 4°: Tube and hollow bar
 - 6°: Tube and solid bar
 - 8°: Solid bar
 - 15°: Small diameter solid bar
- Neutral type inserts are recommended for parts that allow burrs

	Tool Life	Burr Size	Straightness	Surface Finish	Chip Flow
Neutral	✓		✓	✓	✓
Handed		✓			


Maximum Feed and Depth in Turning

- Max. feed rate and depth of cut depends on insert width W in turning

$$\text{Max. Feed rate} \\ f_n = W \times 0.075 \text{ (mm/rev)}$$




$$\text{Max. Depth of cut} \\ a_p = W \times 0.8 \text{ (mm)}$$





Principles of Turning with Groove-Turn Tools

The basic principle in turning with groove-turn tools is the deflection of the cutting tool, which results in a frontal clearance angle α° between the insert and the workpiece. The clearance angle α° is a function of the side cutting forces and is not constant, as is the case with ISO inserts.



Influenced factors of deflection:

- ✓ Feed f
- ✓ Depth of Cut a_p
- ✓ Overhang of Insert Support CDX
- ✓ Width of Insert Support WB
- ✓ Cutting Speed V_c
- ✓ Workpiece Materials


When all of the above factors remain constant during turning, a high degree of accuracy with a tolerance up to ± 0.01 mm can be achieved.

✗ In very light machining, such as super finishing, there is not enough deflection, which can cause chatter and vibration.

Groove-Turning with Compensation Factor


: To eliminate the difference in the workpiece diameter when groove-turning

- Compensation factor must be used in the final finishing groove-turn operation



Recommended Overhang for Internal Machining


: To minimize vibration and good surface finish




Shank Type	Recommended Overhang (L_{Max})
Steel Shank	$L_{Max} \leq 3D$
Tungsten Carbide Shank	$L_{Max} \leq 5D$
Anti-vibration bar	$L_{Max} \leq 7D$

Efficient Use of Insert Corner

: To reduce machining time and improve tool life




Tool Selection for Face Turning and Face Grooving



Facing Tool Adjustment

: Prior to machining, check and adjust the following tool positions





Trouble

Solutions



1 Use high feed and high productivity inserts



High feed and extraordinarily stable machining



High feed machining. Reinforced insert geometry




CBN insert for high feed finish turning on hardened steel

2 Use high-pressure coolant (Max. 70bar)

-TB Holder (2x speed up) **COOLBURST**



3 Use of multiple application tools with multiple cutting edges



Productivity


Trouble

Solutions





Tangled Chip

1 Change cutting conditions



2 Change insert geometry



3 Use pecking (dwelling)

4 Use high-pressure coolant (Max. 70bar)



-TB Holder **COOLBURST**



1 Change cutting conditions




2 Change insert geometry



3 Use high-pressure coolant (Max. 70bar)

-TB Holder **COOLBURST**




Chip Jamming




Trouble

Solutions






Bad Surface Finish

1 Change cutting conditions



2 Change insert geometry



3 Improve stability of the tool and workpiece

4 Use high-pressure coolant (Max. 70bar)

-TB Holder **COOLBURST**



Trouble

Solutions





Shorter Tool Life



1 Check the cutting edge height




2 Check the angle between tool and workpiece



3 Check the damage of the insert seat located in the tool




4 Decrease the feed rate near the center in parting operations



5 Machining with recommended speed and feed

6 Increase the coolant volume or use high-pressure coolant






Vibration



1 Change cutting conditions



2 Change insert geometry




3 Use strong holder and short overhang tool



The Right Choice


Technical Guide Book

The Right Choice



Drilling

Selection Guide
Technical Tips
Troubleshooting




	Hole tolerance (mm)	Application	Recommended drill series	Diameter range
Rough		 Medium to large	 TOP 2/3/4/5D	Direct mounting Ø12.0 - Ø50.0 mm Cartridge type Ø51.0 - Ø80.0 mm
		 Medium to large	 TNDH (Head) MDB-3/5/7D (Body)	Ø26.0 - Ø50.0 mm
General		 Medium to large	 LCD-3/5/8D	Ø20.0 - Ø41.0 mm
		 Small to medium	 TCD-1.5/3/5/8/12D	Ø4.0 - Ø25.9 mm
High Productivity		 Small to medium	 3ED-3/5/8D	Ø12.0 - Ø25.9 mm
		 Small hole drilling	 3HD-PI3/PI5/PI8 3HD-CI2	Ø4.0 - Ø12.0 mm



ISO materials			
	 for Alloy steel SOMT-DP TT9080 Vc 180 - 160 - 140 fn 0.08 - 0.12 - 0.14	 for Low carbon steel SOMT-DL TT9080 Vc 220 - 180 - 160 fn 0.06 - 0.08 - 0.10	 SOMT-DK TT6080 Vc 200 - 160 - 140 fn 0.10 - 0.15 - 0.20
 *N: SOMT-DA			
	 TCD-P-CO+ SPGX-DW TT9080 Vc 180 - 140 - 100 fn 0.20 - 0.25 - 0.35	-	 TCD-P-CO+ SPGX-DW TT9080 Vc 200 - 160 - 120 fn 0.20 - 0.30 - 0.50
	 LCD-P/P+ TT9080 Vc 200 - 100 - 80 fn 0.20 - 0.25 - 0.30	 LCD-P TT9080 Vc 80 - 60 - 70 fn 0.12 - 0.20 - 0.25	 LCD-P/P+ TT9080 Vc 150 - 120 - 100 fn 0.20 - 0.35 - 0.50
 *N: TCD-N			
	 TCD-P/P+ TT9080 Vc 200 - 100 - 70 fn 0.20 - 0.25 - 0.30	 TCD-M TT9080 Vc 70 - 60 - 50 fn 0.12 - 0.18 - 0.25	 TCD-K TT9080 Vc 150 - 120 - 100 fn 0.20 - 0.27 - 0.35
	 3ED-P+ TT5130 Vc 140 - 100 - 70 fn 0.30 - 0.40 - 0.55	-	 3ED-P+ TT5130 Vc 160 - 120 - 80 fn 0.40 - 0.50 - 0.60
	 3HD TT5130 Vc 140 - 100 - 70 fn 0.20 - 0.35 - 0.55	-	 3HD TT5130 Vc 140 - 100 - 80 fn 0.25 - 0.45 - 0.60

(Vc, m/min, fn, mm/rev)




Solid Carbide Drill and Head Changeable Drill Set-up


- The drilling run-out should not exceed **0.02 mm**
- Use a drill with as short an overhang as possible



Rotating drill: for machining center






Stationary drill: for lathe




Indexable Drill Set-up on the Lathe

- On first hole
 - Retract the drill after drilling to a depth of **3-6 mm**
 - Check if it has produced a small core within **0.2-0.7 mm**




Causes insert breakage and vibration. Adjust the drill body after rotating 180 degrees.



Causes overload and vibration. Adjust offsets to bring core to correct size.

- Tool eccentric position by machined hole condition (Ø47 TOP-DRILL)




Tool Position	Core Size	Hole Diameter	Problem
Correct	0.2 mm	47 mm	Correct performance and diameter
A	0.2 mm	48 mm	Hole diameter incorrect
B	0.2 mm	46 mm	Holder interferes with work piece
C	1.2 mm	47.2 mm	Vibration
D	None	46.8 mm	Insert breakage and vibration

Recommended Drill Holder

Indexable drill




Solid carbide drill & head changeable drill



Indication of Tool Life


: Tool life is judged based on the following

Power restriction




25% more cutting load than initial

Wear limit




Frank wear on the head or insert cutting edge 0.2-0.3 mm

Surface finish declines



Poor hole surface roughness

Diameter change



Unstable hole diameter


Vibration noise



Vibration noise drastically increases

Coolant Supply

For Stationary Drill



For Rotating Drill





Trouble



Productivity

Solutions



1 Use high productivity drill



Head changeable
3-flute drill



Solid carbide
3-flute drill

2 Use self-centering drill head (no-pilot drill)



TCD-P+



3ED-P+



LCD-P+

1 Increase coolant pressure and volume



2 Change cutting conditions



3 Use self-centering drill head (no-pilot drill)



TCD-P+







3ED-P+




LCD-P+

4 Check alignment and drill runout




Bad
Surface Finish

Trouble



Oversized Hole






Undersized Hole


Solutions



1 Check alignment and drill runout



2 Increase coolant pressure and volume



3 Change to tougher grade




Tougher

TT8020

TT9030

4 Change cutting conditions





Trouble

Solutions



Chip Jamming


1 Check the cutting conditions and geometry

FEED & SPEED



2 Change coolant conditions

Supply method



Pressure and Volume



3 Change cutting conditions




Overhang



Trouble

Solutions



Insert Breakage

1 Change to tougher grade



Tougher

TT8020

↑

TT9030

↑

TT9080

TT6080 → TT9300 → TT7400 → TT5130 → TT9080

2 Change cutting conditions




Overhang




3 Check alignment and clamping

Alignment




Clamping




Vibration

1 Improve rigidity and stability

Overhang



Clamping



2 Check the cutting conditions and geometry

FEED & SPEED



3 Change cutting conditions



Shorter Tool Life

1 Increase coolant pressure and volume




2 Check the cutting conditions and insert grade

FEED & SPEED




3 Check alignment and clamping

Alignment



Clamping



The Right Choice

Technical Guide Book

The Right Choice



Milling

Section Guide
Troubleshooting



Tool Selection by Application

		TT9080 (TT8080)	TT8080 (TT8020)	TT6080 (TT7515)	K10 (PCD)	TT8080 (TT8020)	TT2510 (CBN)
 Shouldering	End mill	1 st AVKT-M	 AVKT-EL	 LPKU-M	 4NHT-AL	 AVKT-EL	 LPKU-M
		2 nd CVKT-M	 CVK(H)T-ML	 SQKU-M	 AVCT-AL	 3PK(H)T-ML	 4NKT-M
	Face mill	1 st SQKU-M	 4NHT-ML	 LPKU-M	 4NHT-AL	 3PK(H)T-ML	 LPKU-M
		2 nd LPKU-M	 3PKT-ML	 SQK(H)U-M/MM	 3PHT-AL	 3PK(H)T-ML	 SQKU-M
 Slotting	End mill	1 st 4NKT-M	 AVKT-M/L	 LPKU-M	 4NHT-AL	 AVKT-EL	 LPKU-M
		2 nd CVKT-M	 CVK(H)T-ML	 4NKT-M	 XEVT-AL	 3PK(H)T-ML	 4NKT-M
 Facing	Roughing	1 st HXKU	 7EMT	 HXHU-MM	 4NHT-AL	 7EMT-ML	 PTKU-M
		2 nd XNMU-M	 HXKU-ML	 XNHU-MM	 3PHT-AL	 HXKU-ML	 RYHX-MR
	Finishing	1 st 4WHU-ML CT7000	 SNGX-ML	 4WHU-ML, CBN	 4WHU-AL, PCD	 SNGX-ML	 4WHU-CBN

1st : First recommendation
2nd : Second recommendation



Tool Selection by Application


		TT9080 (TT8080)	TT8080 (TT8020)	TT6080 (TT9080, TT2510)	K10 (PCD)	TT8080 (TT8020)	TT2510 (CBN)
 High Feed Milling	End mill	1 st BLMV-M	 AVKT-HF	 PTKU-M	 XEVT-AL Big R	 SBMT-ML	 BLMV-M
		2 nd AVKT-HF	 BLMV-MM	 BLMV-M		 BLMV-ML	 4NKT-HF
	Face mill	1 st BLMV-M	 BLMV-MM	 PTKU-M	 XEVT-AL Big R	 SBMT-ML	 BLMV-M
		2 nd PTKU-M	 PTKU-ML	 BLMV-M		 BLMV-ML	 PTKU-M

1st : First recommendation
2nd : Second recommendation


		TT9080	TT8080	TT9080 (TT2510)	TT8080	TT2510
 Profiling	Roughing	Ø16-Ø32 2FB-M	 2FB-ML	 2FB-M	 2FB-ML	 2FB-M
		Ø32, Ø50 3FB-M	 3FB-M	 3FB-M	 3FB-M	 3FB-M
		Ø50 6RBE	 6RBE	 6RBE	 6RBE	 6RBE
	Medium	 BRHU	 BRHU	 BRHU	 BRHU	 BRHU
	Finishing	 NFB TT5515	 NFLB NFCB	 NFB TT5515	 NFLB NFCB	 NFLB NFCB




Tool Selection by Entering Angle and Depth of Cut



Properties by Cutter Pitch



Chip Former and Grade Selection Map





Trouble

Solutions



1 Use high feed and high productivity insert

WINFEED

BLMV
"V" Shape
Bottom Design

CHASE4FEED

BLMP
Double-sided
4-corner

CHASEFEED

SBMT
Single-sided
4-corner

CHASE2FEED

BLMP 13
Double-sided
6-corner

WINMILL




AVKT -HF

CHASE10MILL

PTKU
Double-sided
10-cornerFor
high feed

CERAMIC SPEED

BNGX
Ceramic insert
4/6-corner

WINMILL



CVKT -HF

CHASE4MILL



4NKT -HF

2 Use chip splitter insert (-SM)

CHASEMILL



APKT -SM

CHASE2MILL



ANHX -SM

MILLRUSH



3PKT -SM

• More suitable for extended flute cutters

3 Use fine pitch cutter (more teeth, same diameter)


CHASE3MILL

Ø125 mm
Z=18 teeth

CHASE2MILL

Ø100 mm
Z=11 teeth

WINMILL


Ø10 mm
Z=3 teeth

Trouble


Solutions





1 Change cutting conditions

Apply feed with
optimum chip thickness




2 Change insert and holder geometry



3 Use wiper insert and combination cutter





4 Use carbide shank or reinforced shank



Bad
Surface Finish

Burr



1 Change insert and holder geometry



2 Use down milling




3 Chamfering at start/end of workpiece



Productivity



Trouble




Back Cutting


Solutions



1 Change axial rake angle



Negative Rake Angle




Positive Rake Angle

2 Change cutter entering angle




Small entering angle




Large entering angle

3 Change depth of cut




High depth




Low depth

4 Use tilting or inclined machining



Feed



Feed

Trouble




Vibration

Solutions




1 Reduce cutting forces

Cutter pitch




Coarse pitch

Pitch spacing




Unequal spacing

Depth of cut




Low depth

Entering angle



Small angle

Chip former



Sharper




Apply feed with optimum chip thickness




2 Improve rigidity and stability

Overhang



Short overhang

Core size



Big core

Rigidity



High rigidity


Tool holder type



C-ADAPTER

Chip Jamming
(full slotting or
extended cutter)

1 Use internal coolant cutter



2 Change cutting conditions



Apply feed with optimum chip thickness



3 Change insert and cutter geometry

Cutting edge



Chip splitter

Cutter pitch



Coarse pitch

The Right Choice

Technical Guide Book

The Right Choice



Solid End Mills

Selection Guide
Recommended Cases
Troubleshooting



Tool Selection by Material









General Purpose			Special Purpose	
	Geometry	1 st Recommendation	Special purpose	1 st Recommendation
	Flat 	UHP	High feed	HFM
	Corner R 	UHP	Chamfering	CEM ECEM
	Ball 	SBE	Roughing	REL
	Flat 	SED	Roughing	SER
	Corner R 			
	Ball 	SBT		
	Flat 	AES	Waved cutting edge	AWE
	Corner R 	AEB	Roughing	REA
	Ball 			
	Flat 	HSF	CBN Ball	HSB 2CBN
	Corner R 	HSR		
	Ball 	HSB		
For Trochoidal 			For Inconel	
	Corner R 	SED 7 TT5515	Ceramic end mill corner R	CRF TC3030
			Ceramic end mill high feed	CRH TC3030




Tool Selection by Application

	Flat	UHP	SED 4/7	HSF 4/6	AES 3
	Corner R	UHP		HSR 4/6	
	Flat	UHP	SED 4/7	HSF 2	AES 2/3
	Corner R	UHP		HSR 2	
	Ball	SBE 2/4	SBT	HSB	AEB

Tool Selection by Application - **MAXIRUSH**

				
				
Shouldering	MXES	MXED	MXEE-A03	MXFX
				
Slotting	MXES	MXEE-A02	MXC_	
				
Profiling (finishing)	MXRD / MXBD(E)	MXBE-BGA02	TTRD	
				
Profiling (5-axis)	MXCSO / MXCSL	Ta-C Coating	TST/TTB	

In case of many tool changes




Long tool change time




Quick head change on machine

In case of lower axial depth of cut with long overhang




Long cutting edge




Short cutting edge

In case of deep cavity machining without interference




Tool and workpiece contact




Optimized for cavity machining

In case of bigger cutter diameter with high tool cost



High tool material cost



Low tool material cost



Trouble



Productivity

Solutions



1 Use high productivity and high feed end mill

MAXIRUSH

Minimize tool change time
and machine down time


MAXIRUSH SOLIDFEED




High feed machining

2 Change machining method

: In case of hardened material or super alloys




Conventional slotting



Trochoidal milling

High Depth
Wide Width

Trouble



Pull out of the tool

Solutions



1 Change the holder with strong gripping power





Normal gripping power



Strong gripping power

2 Change tool helix angle

High helix
angleLow helix
angle

3 Change cutting conditions



Tool Breakage

1 Reduce number of flutes





Narrow chip space




Less number of flute

More space for
chip evacuation

2 Minimize tool overhang

Long
overhangReduced
vibration

3 Change cutting conditions

Rough
Surface Finish

1 Change cutting conditions



2 Change tool holder





Normal run out accuracy



Excellent run out accuracy

3 Minimize tool overhang

Long
overhangReduced
vibration



TaeguTools

★ ★ Ferramentas Premium ★ ★

SIGA NAS REDES SOCIAIS:

  **@taegutools**

SOLICITE COTAÇÃO:

vendas@taegutools.com.br

(19) 3433-1118